


# StatusLight SMART ANDON

## VISUAL FACTORY CONFIGURATOR



### User Configurable Features

Web based configuration utility; no software to install

Configure all StatusLight family devices (StatusLights, Wireless Sounder, LED/LCD Displays, Wireless Gateway, etc.) from one location

Make configuration changes on one device and have those changes automatically propagated to all devices on the network

Point and click graphical user interface makes it easy to configure everything from RFID or Barcode input to complex remote light control

Create local data variables that can be accessed via Modbus TCP

Create a connection to StatusWatch for sending data about current light state or input from Barcodes, etc.

Create triggers on one StatusLight to perform actions on one or more other StatusLights

**SCADAware**

1602 Rhodes Lane, Bloomington, IL 61704 • 309-665-0135 | Fax: 309-665-0975 • info@scadaware.com | www.scadaware.com